

Spare parts recommended to keep on site for FlexStand™ Low Void Volume Holders, FS-03LVS and FS-03LVS-30, and FlexStand Low Void Volume Systems, FS-04LVS-RLP and FS-04LVS-RLP/50.

Seals and tubing are considered as consumables and should be replaced annually or when needed. Inspect the seals and tubing for wear regularly. Please keep a set of each in your stock to prevent long downtime. For code numbers refer to the table below.

Description	Quantity / pack	Material	Code No.	Model no
Gasket 25 mm i.d. 13 mm (0.5 inch)	4	Silicone	56-4109-94	KG4S
Gasket 25 mm i.d. 19 mm (0.75 inch)	4	Silicone	56-4109-95	KG6S
Gasket 50 mm i.d. 38 mm (1.5 inch)	4	Silicone	56-4109-96	KG12S
Tubing i.d. 3.1 mm (0.12 inch)	Length=3.1 m (10 feet)	Silicone	56-4106-17	PTSL03-10
Tubing i.d. 6.4 mm (0.25 inch)	Length=3.1 m (10 feet)	Bioprene™	56-4106-18	PTPM06-10
Tubing i.d. 9.5 mm (0.375 inch)	Length=3.1 m (10 feet)	Bioprene	56-4106-19	PTPM09-10
Tubing i.d. 13 mm (0.5 inch)	Length=7.6 m (25 feet)	Bioprene	56-4106-22	PTPM12